

GTD-F5 BSW DMX CHANNEL

27ch Standard	25ch Basic	35ch Extended	數值	Function
CH1	CH1	CH1	0~255	頻閃/遮光 Strobe/Shutter
CH2	CH2	CH2	0~255	調光 Intensity
-	-	CH3	0~255	調光微調 Intensity Fine
CH3	CH3	CH4	0~255	青色 Cyan
-	-	CH5	0~255	青色微調 Cyan Fine
CH4	CH4	CH6	0~255	品紅色 Magenta
-	-	CH7	0~255	品紅色微調 Magenta Fine
CH5	CH5	CH8	0~255	黃色 Yellow
-	-	CH9	0~255	黃色微調 Yellow Fine
CH6	CH6	CH10	0~255	色溫 CTO
-	-	CH11	0~255	色溫微調 Color Temperature 16bit
CH7	CH7	CH12	0~255	CMY 宏功能 CMY Color Macro
CH8	CH8	CH13	0~255	顏色盤 1 Color Wheel 1
CH9	CH9	CH14	0~255	顏色盤 2 Color Wheel 2
CH10	CH10	CH15	0~255	固定圖案盤 GOBO Wheel
CH11	CH11	CH16	0~255	自轉圖案盤 Rotating GOBO Wheel
CH12	CH12	CH17	0~255	圖案旋轉 GOBO Rotating
-	-	CH18	0~255	圖案旋微調 GOBO Rotating Fine
CH13	CH13	CH19	0~255	效果盤 Effect Wheel
CH14	CH14	CH20	0~255	對焦 Focus
-	-	CH21	0~255	對焦微調 Focus Fine
CH15	CH15	CH22	0~255	光圈 Iris
-	-	CH23	0~255	光圈微調 Iris Fine
CH16	CH16	CH24	0~255	稜鏡 1 Prism 1

CH17	CH17	CH25	0~255	稜鏡 1 旋轉 Prism 1 Rotation Position
CH18	CH18	CH26	0~255	稜鏡 2 Prism 2
CH19	CH19	CH27	0~255	稜鏡 2 旋轉 Prism 2 Rotation Position
CH20	CH20	CH28	0~255	稜鏡宏功能 Prism Marco
CH21	CH21	CH29	0~255	霧化 Frost
CH22	CH22	CH30	0~255	水平 Pan
CH23	-	CH31	0~255	水平微調 Pan Fine
CH24	CH23	CH32	0~255	垂直 Tilt
CH25	-	CH33	0~255	垂直微調 Tilt Fine
CH26	CH24	CH34	0~255	水平/垂直速度 Pan/Tilt Speed
CH27	CH25	CH35	0~255	功能控制 Function